

1. Place top plate Umbria



2. Mount the top plate with the screws



3. 6 screws tightened end Umbria is ready.

