


BOLEA



INSTRUCTION




IMPORTANT: Please read this instruction carefully, keep for further reference and check all parts before assembling.

Xaralyn B.V.

info@xaralyn.com
www.xaralyn.com




For A,F




For B,D

 8x35 Ax6	 ø15 Bx14	 6x45 Cx6	 6x35 Dx2
 7x35 Ex4	 For E x1	 4x45 F x 4	

1



2




3



Cx2



Fx4




3



Bx2

4




4



Bx2

5





5






Bx4

6






7



Adjusting

8




9


5



5



1.



2.

